

Harden X SI™

Lithium Hardener/Sealer/Densifier/ Salt Inhibitor



383 Canterbury Road Surrey Hills 3127

TEL: 61 3 9836 4488

SALES / TECH SUPPORT: 0411 248 486

www.sealsourceaustralia.com

PRODUCT APPLICATION

Harden X SI™ may be applied to new concrete immediately after final trowel or to existing concrete of any age. Proper surface preparation and product application is essential to performance. For optimum results, please read instructions in full and contact our Technical Support department at +61 (0)411 248 486 for additional customized instructions prior to application.

Always test the surface to be treated for suitability and desired results. Let surface dry before assessing results of test application.

Equipment Needed for Application

- **Horizontal application:** HVLP, pump-up, airless, backpack, or mechanical sprayer
- **Vertical application:** Sprayer or roller with ¾" nap
- Soft broom or 100% polyester microfiber pads (to spread out any excess material)

Surface Preparation & Product Application

New Concrete

Harden X SI™ may be applied to new concrete immediately after final trowel or at any point thereafter. If applying to acid-stained or integrally-pigmented concrete floors, please take note the modifications below.

1. Thoroughly clean and scrub the surface to be treated, removing any substance that may interfere with penetration—including any bond breakers, form release oils, wax, surface laitance, curing compounds, drywall residue, dust, or other contaminants. Acid-stained surfaces must be neutralized prior to application by washing and scrubbing. Allow surface to dry completely before application.
(If applying to new concrete floors after joints have been cut, carefully clean saw-cut residue from the surface with vacuums, sweepers, blowers, or brooms. Appropriate scrubber equipment with a red pad may be used to remove any remaining residue from the joints. If necessary, damp mop the joints and around columns to ensure surface is thoroughly clean. Allow surface to dry completely before application.)
2. Using a HVLP, pump-up, airless, backpack, or mechanical sprayer, apply **Harden X SI™** at 10-12 m² per liter (400-500 sq/ft per gallon), maintaining a consistent, even spray. Do not allow the material to puddle (lightly broom out any excess material immediately after spraying).
3. The entire surface **MUST** remain wet with **Harden X SI™** for 30 minutes to allow the material to react properly with the surface. **DO NOT LET ANY AREA DRY OUT** – apply more **Harden X SI™** if necessary to keep the surface wet - **DO NOT USE WATER**. After the wet material has reacted with

the surface for 30 minutes, allow material to dry (if applying to acid-stained or integrally-colored concrete, see modification below.) Material should dry in 1-2 hours and will be ready for traffic as soon as it dries.

Modification for Acid-Stained or Integrally-Colored Concrete: After keeping surface wet for 30 minutes, spray water on the surface to saturate it completely. To ensure a uniform finish, do not let any area of the surface dry prior to cleaning. Remove excess residue with a scrubber equipped with a red pad. With the squeegee down, vacuum on, and light head pressure, add water, scrub, and clean the surface to remove all excess residue. Dispose of excess material according to local regulations.

Tilt-Up Construction Applications

Please contact SealSource® technical support services for specific instructions.

Existing (Cured) Concrete

Harden X SI™ may be applied to existing, cured concrete of any age that is structurally sound.

1. Mechanically remove any surface laitance and patch or fill any cracks or other surface damage.
2. Remove dirt, dust, oil, grease, membrane-forming curing compounds, coatings, sealers, or other contaminants or substances that may interfere with penetration.
3. For maximum penetration, sand blast or shot blast concrete with a 60-100 grit sanding screen or diamond abrasive pad. SealSource® recommends mechanical surface preparation when possible, however older concrete may require more aggressive preparation. If using acid etch or other chemical preparation, the surface **MUST** be neutralized with a pH neutral cleanser to prevent whitening. (Please call SealSource® technical support for specific instructions.)
4. Remove any remaining dirt, contaminants, and dust caused by grinding with a riding or walk-behind scrubbing machine with water or broom following by a water rinse. Squeegee dry or allow to dry completely prior to application.
5. Using a HVLP, pump-up, airless, backpack, or mechanical sprayer apply **Harden X SI™** at 10-12 m² per liter (400-500 sq/ft per gallon), maintaining a consistent, even spray. Do not allow the material to puddle (lightly broom out any excess material immediately after spraying).
6. The entire surface **MUST** remain wet with **Harden X SI™** for 30 minutes to allow the material to react properly with the surface. **DO NOT LET ANY AREA DRY OUT** – apply more **Harden X SI™** if necessary to keep the surface wet - **DO NOT USE WATER**. After the wet material has reacted with the surface for 30 minutes, allow material to dry.) Material should dry in 1-2 hours and will be ready for traffic as soon as it dries.

Vertical Application

Prepare surface as directed above for either new or existing concrete and apply using one of the following methods:

Spray Method: Apply **Harden X SI™** from the bottom up using a low pressure, 10-24 psi sprayer (68.9 – 172 kPa). Flood surface until excess runs down 15-20 cm (6-8 inches) below spray pattern, or sponge to create a uniform wet appearance. On horizontal surfaces, proper quantity is indicated when the material stands on the surface for a few seconds before completely penetrating. For maximum vertical penetration and desired coverage rates, “wet-

on-wet” application is recommended. Re-apply **Harden X SI™** as above within 3-5 minutes after initial application. Use a broom to distribute any accumulated material.

Roller Method: If applying with a roller, apply in multiple coats until the surface remains moist for approximately one minute before the material disappears. Use a broom to distribute any accumulated material.

Application in Extreme Weather Conditions

High Humidity – Apply **Harden X SI™** as above. After the material has reacted for 30 minutes, remove any excess material that has not penetrated the surface. Do not allow excess material to air-dry.

High Temperatures (Above 90° F or 32° C) – To prevent **Harden X SI™** from flashing/drying too quickly, the area to be treated may be sprayed with water to cool the surface prior to application. Allow the surface to dry completely before applying the material. **Harden X SI™** may also be applied by spraying out at 30-40 m² per liter (800-1000 sq/ft per gallon) in three thin coats, using 100% polyester microfiber pads to spread the material.

Low Temperatures (Below 40° F or 4° C) – Apply **Harden X SI™** as above. While keeping the surface wet for 30 minutes, agitate the material using red pads on a scrubbing machine, floor machine or swing buffer. Because of the need to agitate the material once it has been applied, apply to a smaller square footage which can be successfully managed.

Product Disclaimers

Harden X SI™ is not suitable for asphalt surfaces and should not be applied to glazed brick or tiles.

Harden X SI™ is not intended to be used as a waterproofing material. For above grade use only.

Harden X SI™ will not bridge water intrusion of visible cracks of 10 mils or larger and is not designed for use on surfaces experiencing hydrostatic pressure.

Application and coverage rates are estimated and may vary depending on the porosity of substrate and environmental conditions present during application. For precise rates of consumption, a pre-application field test should be performed.

It is highly recommended that the installer contact our Technical Support department at +61 (0)411 248 486 for customized instructions prior to application. Proper application is the responsibility of the user.

DO NOT ALLOW SEALSOURCE® PRODUCTS TO FREEZE